

HERO3⁺

BLACK EDITION

/ Hello

Congratulations on your new HERO3+. This Quick Start Guide will help you learn the basics of capturing life's most incredible moments with your GoPro.

JOIN THE GOPRO MOVEMENT



facebook.com/GoPro



youtube.com/GoPro



twitter.com/GoPro





instagram.com/GoPro

/ Getting Started

1


REMOVE CAMERA FROM HOUSING



2

REMOVE CAMERA SIDE DOOR AND INSERT MICROSD CARD

(Class 10 required, sold separately)




3

REMOVE CAMERA BACK DOOR AND INSERT BATTERY



4

CHARGE BATTERY USING INCLUDED USB CABLE



/ Camera Essentials

Shutter/Select Button []

Camera Status Light [red]


LCD Status Screen

Power/Mode Button []

Wi-Fi On/Off Button []

Wi-Fi Status Light [blue]

Camera Status Light [red]



POWERING CAMERA ON AND OFF

To power **ON**

Press the Power/Mode Button [].

To power **OFF**

Press and hold the Power/Mode Button [] for two seconds.

/ Selecting Camera Modes

Turn camera **ON** and repeatedly press the Power/Mode Button [] to cycle through camera modes.



VIDEO

Record video



PHOTO

Capture a single photo



BURST PHOTO

Capture photo bursts



TIME LAPSE

Shoot a series of photos
at set time intervals



SETTINGS

Adjust camera settings,
resolution and more



PLAYBACK*


View your videos
and photos on a
TV or LCD Touch
BacPac™

**Playback only appears when camera is connected to a TV or LCD Touch BacPac (optional accessory, sold separately).*

/ Camera Settings*


TO ADJUST CAMERA SETTINGS:

1. Press the Power/Mode Button [] to cycle to Settings mode [].
2. Press the Shutter/Select Button [] to enter the Settings menu.
3. Press the Power/Mode Button [] to cycle through options.
4. Press the Shutter/Select Button [] to select desired option.



*For a full explanation of camera settings, see the User Manual.

/ Capturing Video + Photos



Press the Shutter/Select Button
[] to start/stop recording or
take a photo.

You can change video and photo
settings in the Settings menu [].

/ Default Video + Photo Settings

DEFAULT VIDEO SETTING: 1080P SUPERVIEW 30 FPS




SUPER VIEW

SuperView delivers the world's most immersive wide angle video, making it easier than ever to capture the shot.

If you want to experiment with other video settings, you can find more info in the Camera Settings section of the User Manual.

DEFAULT PHOTO SETTING: 12MP



Your camera is set to 12MP resolution, allowing you to capture stunning high-resolution photos.

You can adjust photo resolution in the Settings menu [].

/ Pairing Camera to Wi-Fi Remote

Before using the Wi-Fi Remote for the first time, you must pair it with your camera.

A. ON THE CAMERA:

1. Ensure both camera and remote are powered **OFF**.
2. Press the Power/Mode Button [] to power camera **ON**.
3. Press the Wi-Fi On/Off Button [] twice, then press the Shutter/Select Button [] to enter the **Wi-Fi** menu [].
4. Press the Power/Mode Button [] to cycle to **Wi-Fi RC**, then press the Shutter/Select Button [] to select it.
5. Press the Power/Mode Button [] to cycle to **NEW**, then press the Shutter/Select Button [] to select it. You will see [].

B. ON THE WI-FI REMOTE:

1. While holding down the Shutter/Select Button [], press and release the Power/Mode Button [].
2. When you see [], release the Shutter/Select Button [].
3. [] will appear once camera and remote have paired.
4. The remote will now prompt **CONNECT ANOTHER?** camera. If you want to connect additional cameras at this time, press the Shutter/Select Button [] to select **YES**. If not, press the Power/Mode Button [] to cycle to **NO**, then press the Shutter/Select Button [] to select it.

/ Connecting to the GoPro App

The GoPro App lets you control your camera remotely using a smartphone or tablet. Features include full camera control, live preview, playback and sharing of select content and more*.

1. Download the GoPro App to your smartphone or tablet at the Apple App Store, Google Play or Windows Phone marketplace.
2. Press the Power/Mode Button [] to power camera **ON**.
3. Press the Wi-Fi On/Off Button [] twice, then press the Shutter/Select Button [] to enter the **Wi-Fi** menu [].
4. Press the Power/Mode Button [] to cycle to **GoPro App**, then press the Shutter/Select Button [] to select it.
5. In your smartphone or tablet's Wi-Fi settings, connect to the network called "GOPRO-BP" followed by a series of numbers/ letters. Enter the password "goprohero"**.
6. Open the GoPro App on your smartphone or tablet.



**For device compatibility, please visit gopro.com.*

***This is the default network name and password. You can customize this if you update your camera software at gopro.com/update.*

/ Playing Back Videos and Photos

There are several ways to play back your videos and view your photos.



LCD TOUCH BACPAC™

Removable LCD touch screen
(sold separately).



TV

Connect via Micro HDMI, Composite
or Combo Cable (sold separately).



GOPRO APP

Play back and share select content
using your smartphone or tablet.





COMPUTER

Connect via included USB cable.



/ Mounting Your Camera

Attach your HERO3+ to helmets, gear and equipment.



FLAT SURFACE MOUNTING*



CURVED SURFACE MOUNTING*




VERTICAL MOUNTING



**Not included with HERO3+ Black Edition/Surf.*


/ Mounting Your Camera (Continued)

SIDE MOUNTING



SURFBOARD MOUNTS

Included with HERO3+ Black Edition/Surf only.



NOTE: To remove adhesive mounts, heat with a hair dryer then peel off mount.

/ Help + Resources

CUSTOMER SUPPORT

GoPro is dedicated to providing the best possible service. To reach GoPro Customer Support, visit **gopro.com/support**.

GOPRO TUTORIAL VIDEOS

How-to tutorials, pro tips and tricks to help you make the most of your GoPro products. Visit **youtube.com/goprotutorials**.

CAMERA SOFTWARE UPDATES

To get the latest features and best performance from your HERO3+, make sure you're using the most current camera software. To check for available updates and download the latest camera software, visit **gopro.com/update**.